



- 1 To keep the correct order of the lines during the installation of the soft link, pass the soft link through the lines without removing the plastic.
- 2 Once soft link is completely through line group, remove the plastic.
- 3 Pass the soft link through the riser completing the first loop.
- 4 Then, pass the soft link through the line group and riser a second time to complete the second loop.



- 5 Pass the loop end of the soft link through the opening under the red tab.
- 6 Insert the red tab through the loop end of the soft link and pull tight.
- 7 Pull on lines and riser simultaneously to even the length of the 2 link passes, and place the tab inside the riser.
- 8 Sew one hand tack passing through the red tab and attaching only one side of the riser. \*Use Lite Super Tack Cord.



- 9 Pass the needle back through the two layers of the riser, without passing through the red tab.
- 10 Pass the needle back, one last time, through one side of the riser only and in front of the stitch made in point 8.
- 11 Tie a surgeon knot inside of the riser.
- 12 Finally, cut ends of thread, making sure they are not too close to the knots, and check correct assembly.



**Soft Link Installation Instructions**

Reserve Canopies &

Main Canopies using 1 23/32" risers

[www.icarusworld.net](http://www.icarusworld.net)

[Icarus World Support](mailto:support@icarusworld.net)

[support@icarusworld.net](mailto:support@icarusworld.net)

LOT # \_\_\_\_\_

OTEC870043 Rev. 01